





Артикул RGC-0005

Детали амортизатора передней подвески




Front Shocks

Детали амортизатора задней подвески




Rear Shocks


Детали дифференциала



RH511 Rear Diff Box
RH509 Front Diff Box




RH509 Rear Diff Box
RH509 Center Diff Box







RH511 Center Transmission




Детали центральной трансмиссии





Детали двигателя







Система полного привода




Бензиновый двигатель 30 см³

30005 (поршневая группа)

30009 (ручной стартер)

30010 (воздушный фильтр)

30015 (сцепление)




| | | | | |
|------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------|
| RH5011-Steering Unit 1set  | RH5012-Servo Bearer 1pc  | RH5013-Receiver Case 1set "  | RH5014-Battery Case 1pc "  | RH5017-Rear Axle Sleeve Unit 1set "  |
| RH5019-Susp Arm Fixed Holder 8pcs  | RH5020-Diff Gearbox 1pc  | RH5033-Connect Rod for Servo 2sets "  | RH5034-Ball End for Susp. Arm 4pcs " "  | RH5035 -Steering Ball End 4pcs "  |
| RH5036-Ball End for Servo 4pcs  | RH5037-Driven Diff. Gear w/Shaft 1set  | RH5038-Drive Diff. Gear 1set  | RH5039-Outer Diff. Case Cover 1pc  | RH5040-Wheel Rim Coupler Short 2pcs  |
| RH5041-Rear Wheel Shaft 2pcs  | RH5042-Diff Speed Shaft of Rear Wheel 2pcs  | RH5044-Fly wheel 1set  | RH5049-Steering Fixed Rod 1pc  | RH5052-Rear Rim Fixing Shaft 2pcs  |
| RH5071-Fixing Plate 1set  | RH5074-Set collar2.1 4pcs  | RH5076-Steering Rod Washer 8.5*19.6*1.2 2pcs  | RH5077-Steering Rod Washer 6.2*18*1.5 4pcs  | RH5080-Washer 4pcs  |
| RH5082-Brake Disc Clamp Slice 3pcs  | RH5085-Spring of Servo Saver 1pcs  | RH5096-6V Battery Pack 1pcs(Optional)  | RH5098-Antenna Pipe 4sets  | RH5099-Oil pipe 1set  |
| RH5102-Nylon Lock Nut M3 6pcs  | RH5103-Nylon Lock Nut M4 6pcs  | RH5104-Nylon Lock Nut M5 6pcs  | RH5105-Nylon Lock Nut M6 6pcs  | RH5108-E-ring 5mm 6pcs  |
| RH5109-E-ring 6mm 6pcs  | RH5110-E-ring 7mm 6pcs  | RH5111-Ball Bearing 10*19*7 2pcs  | RH5112-Ball Bearing 8*22*7 2pcs  | RH5113-Ball Bearing 10*22*6 2pcs  |

| | | | | |
|---------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------|
| <p>RH5114-Ball Bearing 12*28*8 2pcs</p>  | <p>RH5116-Inner Hex Grub Screw M3*3 6pcs</p>  | <p>RH5117-Inner Hex Grub Screw M4*4 6pcs</p>  | <p>RH5118-Grub Screw M5*5 6pcs</p>  | <p>RH5119-Grub Screw M4*8 6pcs</p>  |
| <p>RH5120-Grub Screw M5*25 2pcs</p>  | <p>RH5121-FH Screw M4*16 6pcs</p>  | <p>RH5122-FH Screw M4*25 6pcs</p>  | <p>RH5123-FH Screw 4*16 6pcs</p>  | <p>RH5126-FH Screw M5*10 6pcs</p>  |
| <p>RH5127-FH Screw M4*8 6Pcs</p>  | <p>RH5128-FH Screw M5x27 6pcs</p>  | <p>RH5130-RH Self Tapping Screw 3*12 6pcs</p>  | <p>RH5131-RH Screw 4*16 6pcs</p>  | <p>RH5132-RH Screw M3*15 6pcs</p>  |
| <p>RH5134-Umbrella Head Screw 3*6 6pcs</p>  | <p>RH5135-RH Self Tapping Screw 4*12 6pcs</p>  | <p>RH5136-RH Self Tapping Screw 4*20 6pcs</p>  | <p>RH5138-Flange Head Self tapping screw M2.6*15 6pcs</p>  | <p>RH5139-Shock Absorber Fixing Screw 6pcs</p>  |
| <p>RH5140-RH Screw M4*20 6pcs</p>  | <p>RH5142-RH Screw M4*45 6pcs</p>  | <p>RH5143-RH Screw M6*40 6pcs</p>  | <p>RH5144-Fixed Pin of Brake Slice Unit 2pcs</p>  | <p>RH5153-Tire Units 2sets</p>  |
| <p>RH5156-Tire and Sponge 2sets</p>  | <p>RH5157-Wheel Rim 2pcs</p>  | <p>RH5158-Truck Tire Sponge 2pcs</p>  | <p>RH5160-Spark Plug 1pcs</p>  | <p>RH5161-Clutch Assy 1set</p>  |
| <p>RH5170-RH Self Tapping Screw M4*6 6pcs</p>  | <p>RH5173-Central Trans- mission Upper Deck 1pcs</p>  | <p>RH5174-Central Gear Bracket 2pcs</p>  | <p>RH5175-Gear 56T 1pcs</p>  | <p>RH5176-FH Screw M4*106pcs</p>  |
| <p>RH5179-Radio Tray Post 4pcs</p>  | <p>RH5180-RH Screw M4*16 6pcs</p>  | <p>RH5183-Brake Post 2pcs</p>  | <p>RH5184-Brake Tube 2pcs</p>  | <p>RH5186-Steering Fixed Rod Holder 1pcs</p>  |

| | | | | |
|-------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------|
| RH5189-Receiver Switch  | RH5190-E-ring M4 6pcs  | RH5191-Lower Susp. Arm Bracket 2pcs  | RH5195-Pin for Front Upper Sus. Arm 2pcs  | RH5196-Pin for Lower Susp. Arm Bracket 2pcs  |
| RH5197-Pin for Front Lower Sus. Arm 2pcs2P  | RH5198-Front Bulkhead 1pcs  | RH5199-Front Diff Drive Cup 1pcs  | RH5400-Gear Box Housing 1set  | RH5401-Diff. Bevel Gear B. 1pcs  |
| RH5402-Diff. Bevel Gear S. 1pcs  | RH5407-BH Screw M5*15 6pcs  | RH5408-FH Screw 5*16 6pcs  | RH5410-Fuel Tank Mount 4pcs  | RH5411-Front Bumper 1pcs  |
| RH5417-RH Screw 4*23 6pcs  | RH5418-Clip 4pcs  | RH5430-Fuel Tank 1set  | RH5432-Wrench 1pc  | RH5434-FH Screw 4*25 6pcs  |
| RH5436-Upper Cover of Shock Absorber 4pcs  | RH5439-Adjusting Ring for Shock Absorber 4pcs  | RH5444-Shocks Absorber Gasket 4pcs  | RH5445-Spacer for Shock Absorbers 4pcs  | RH5446-Shock Absorber Clip 4pcs  |
| RH5447-Fixing of Shock Spring  | RH5448-Large Size Shock Piston 4pcs  | RH5450-Shock Piston Sealing Cap 4pcs  | RH5451-Shock O-ring 4pcs  | RH5452-Shock Absorbers O-ring 8pcs  |
| RH5455-Gear Cover 1pc  | RH5458-RH Screw M4*12 6pcs  | H0005-Throttle Servo 15kg/cm 1pcs  | H0006-Steering Servo 30kg/cm 1pc  | R0004-Printed Body 1pc  |
| R0005-Printed Body 1pc  | R0009-Fail safe(Optional)  | P0002-CY27cc Engine 1pc(Optional)  | P0003-CY29cc Engine 1pc(Optional)  | P0004-CN28.5cc Engine 1pc  |

| | | | | |
|---------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------|
| RH5490-Front shock body 2pcs  | RH5491-Front shock axle 2pcs  | RH5492-Front shock spring 2pcs  | RH5493-Rear shock body 2pcs  | RH5494-Rear shock axle 2pcs  |
| RH5495-Rear shock spring 2pcs  | RH5496-Engine mount (right) 1pc  | RH5497-Gear 14T 1pc  | RH5498-Engine mount (left) 1pc  | RH5499-Fixed brake Block 2pcs  |
| RH5501-Gear 46T 1pc  | RH5502-Gear cover 1pc  | RH5503-Gear 42T 1pc  | RH5504-Brake post 1set  | RH5505-Gear mount 1pc  |
| RH5506-Spacer Sleeve 2pcs  | RH5507-RH Screw M4*20 6pcs  | RH5508-Washer 14.5* 6.5*0.8 6pcs  | RH5509-Spacer 4pcs  | RH5510-Shock upper holder 4pcs  |
| RH5511-Front shock tower 1pc  | RH5512-Front upper sus. arm 2pc  | RH5513-Front lower sus. arm 2pc  | RH5514-Pivot ball nut 4pcs  | RH5515-Pivot ball spacer 4pcs  |
| RH5516-Pivot balls 4pcs  | RH5517-Steering arm 2pc  | RH5518-Washer 12* 8.5*2.0 4pcs  | RH5520-Rear Susp. arm 2set  | RH5521-Rear drive shaft 2pcs  |
| RH5522-Rim stop ring 4pcs  | RH5523-Rear susp. arm 2pcs  | RH5524-Rear shock tower 1pc  | RH5525-M5*28 Round head screw 6pcs  | RH5526-Washer 15* 10.1*0.2 6pcs  |
| RH5527-Steering rod 2set  | RH5528-Upper plate linkage 1pc  | RH5529-Throttle linkage 1set  | RH5530-Brake linkage 1set  | RH5531-Front body mount 2pcs  |

| | | | | |
|-----------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------|
| <p>RH5532-Roll cage front linkage 1pc</p>  | <p>RH5533-Front body mount bracket 2pcs</p>  | <p>RH5534-Roll cage main 1set</p>  | <p>RH5535-Rear body mount 2pcs</p>  | <p>RH5536-Roll cage rear linkage 1pc</p>  |
| <p>RH5537-Foam spacers 6pcs</p>  | <p>RH5538 M4*20 screw 6pcs</p>  | <p>RH5539-Central transmission cover 1pc</p>  | <p>RH5540-Gear 42T 1pc</p>  | <p>RH5541-Front shock 2set</p>  |
| <p>RH5541-Rear shock 2set</p>  | <p>RH5543-Front universal joint shaft 2pcs</p>  | <p>RH5544-Central front drive shaft 1pc</p>  | <p>RH5545-Center rear drive shaft 1pc</p>  | <p>RH5546-Side Plate 1set</p>  |
| <p>RH5547-Chassis plate</p>  | <p>RH5549-Bumper spring 2pcs</p>  | <p>RH5550-Bumper spring holder r. 2pcs</p>  | <p>RH5551-Bumper spring set</p>  | <p>RH5552-Shock cap 4pcs</p>  |
| <p>RH5500-Brake disc 2pcs</p>  | <p>RH5172-Bracket for center trans. drive cup 1pc</p>  | <p>RH5487-Round head screw M4*10 6pcs</p>  | <p>RH5553-Front Wheel shaft 2pcs</p>  | <p>RH5167-Spacer for Shock Absorbers 4pcs</p>  |
| <p>RH5554-Gear case washer 3pcs</p>  | | | | |
| | | | | |
| | | | | |

Upgrade

| | | | | |
|---------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------|
| <p>RH5206-Steering units 1set</p>  | <p>RH5214-Diff gear box 1pc</p>  | <p>RH5217-Rear axle sleeve unit 1set</p>  | <p>RH5220-Alum muffler 1pc</p>  | <p>RH5222-Air cleaner 1set</p>  |
| <p>RH5224-Chromed buggy rims 2pcs</p>  | <p>RH5225-Chromed truck rim 2pcs</p>  | <p>RH5231-Center gear box mount 2pcs</p>  | <p>RH5233-Lower holder for shock absorber 4pcs</p>  | <p>RH5257-Alum steering arm 2pcs</p>  |
| <p>RH5249-Front upper susp. arm(alum.) 2pcs</p>  | <p>RH5250-Front lower susp. arm(alum.) 2pcs</p>  | <p>RH5251-Rear lower susp. arm(alum.) 2pcs</p>  | <p>RH5252-Alum front shock tower 1pc</p>  | <p>RH5253-Alum rear shock tower 1pc</p>  |
| <p>RH5254-Alum gear mount 1pc</p>  | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |